

Support Requirements for Mister Tanks WithOUT Tunnel


Please note the following Mister tanks

- 3000ltr Mister Tank
- 4000ltr Mister Tank
- 5000ltr Mister Tank
- 6000ltr Mister Tank
- 7000Ltr Mister Tank

Require support framing please note in the picture bellow that this is indicative of the support required for all of the mister range of tanks (Support is marked in red).

Please note inadequate support on tank will void warranty.

MINIMUM SUPPORT LOCATIONS – 7000lt HORT TANK.
(Support locations shown in red)



21-1083 22021026

Please note inadequate support on tank will void warranty.